

- 1 Decide what size opening you want (X & Y).
- 2 Decide what the door size needs to be:
 - 10mm under door.
 - 20mm higher than opening X (minimum).
 - 100mm wider than opening Y (50mm each side).
 (If you have architraves around your opening you may want to clear these).
- 3 How long a track needed - Door width x 2.
- 4 Fixing track to wall make sure you have fixing timber in the wall at "door height + 43mm.
- 5 Centre of track should be inline with opening edge Z.
- 6 A 34mm spacer comes standard with tracks, if you require extra clearance due to thick skirting or architraves you can purchase 45mm or 50mm spacers.

