

JOHNSTONE'S PROFESSIONAL
COATING GUIDELINES FOR DURAMAX DOORS

Johnstone's Professional Exterior Timber Oil & Exterior Clear

Extremely durable, fast drying, superior water based transparent oil for timber windows, cladding, bi-folds, gates and doors including Parkwood Duramax composite doors.

Coating System Summary: Duramax Composite Doors

Johnstone's Professional Timber Oil

(Available in Natural, Merbau, Jarrah, Walnut and Teak transparent timber tones)

Johnstone's Professional Exterior Clear

(Available in Satin and Gloss sheen levels and tint-able to 15 trend colours).

- 1st Coat: Johnstone's Professional Exterior Timber Oil
- 2nd Coat: Johnstone's Professional Exterior Timber Oil or Johnstone's Professional Interior/Exterior Clear
- 3rd Coat: Johnstone's Professional Exterior Timber Oil or Johnstone's Professional Interior/Exterior Clear

Spread Rate: Up to 12m²/L per coat

Recoat Time: Allow a minimum of 1 hour between coats

Benefit of 3 x coats: Application of 3 x coats will provide far better overall longevity of the coating system and a longer life cycle

SURFACE PREPARATION

1. Thoroughly wash all surfaces with liquid sugar soap. Rinse with clean water and allow to dry.
2. **Important:** Scuff sand with 120-240 grit sandpaper or medium sanding block. Missing this step will mean the finish is unlikely to adhere.
3. Ensure surface is free from all dust and contaminants prior to applying each coat of Johnstone's Professional Exterior Timber Oil or Johnstone's Interior/Exterior clear.



Application:

1. Stir Johnstone's Exterior Timber Oil/Exterior Clear using a broad paddle stirrer to ensure that the pigments are disbursed throughout the product evenly prior to application
2. Apply 3 coats of Johnstone's Exterior Timber Oil/Exterior Clear using a good quality brush allowing 1 hour between coats.
3. Johnstone's Exterior Timber Oil/Exterior Clear will be touch dry in 30 minutes. Allow 1 hour for recoat at 25deg C. Do not use below 10 deg C, above 35 deg C when humidity is excessive or if rain showers or dew is expected within 6 hours of application. Allow longer dry times at lower temperatures or where high humidity is present.
4. For the necessary PPE requirements please refer to the relative PDS and MSDS for this product located on the website www.johnstoneswoodcare.com.au

CARE & MAINTENANCE

Protect the coating from any abrasive contact for at least four days.

Even a well-finished fiberglass door will be affected by exposure and UV weathering from sun, moisture, and air pollutants. It is considered normal to undergo maintenance when the surface begins to deteriorate, and the sheen level of the coating reduces.

Periodically cleaning the surface of your stained Duramax door with a mild detergent and water solution will remove contaminants which can erode and damage the coating system. This will extend the service life of the coating and ensure better longevity. It is important to recoat the surface when the coating begins to show signs of wear. Simply wash down with a mild detergent and water solution, rinse off and allow to dry. Apply 1 or 2 maintenance coats of Johnstone's Exterior Oil following instructions of back of pack.

parkwooddoors.com.au

1800 681 586

johnstoneswoodcare.com.au

131 686